



example vent for door that is $750w$, $40t$, $20g$

See key in *pattern*

**non-scale measurement*
Drawing is stretched or shrunk in these places to show relationships between components and to condense drawing. All other measurements are to scale.

